



A Division of SCARECROW BIO-ACOUSTIC SYSTEMS LIMITED

### USING C98 MICROPHONE

C98 microphone incorporate moving coil capsules and are suitable for direct connection to the host amplifier microphone input.

**There are three flexibles to connect to your host amplifier:**

#### **XLR VERSIONS/INPUTS**

GREEN :	Screen	PIN 1
RED :	Capsule Output	PIN 2
BLUE :	Capsule Output	PIN 3

### TYPICAL PERFORMANCE DATA

Sensitivity	:	Suitable for all amplifiers with at least 500 mV (0.5mv) switching
Impedance	:	600ohms
Characteristics	:	Polar diagram approximates to cardioid
Frequency response	:	± 6db : 100 Hz to 12 KHz

**ENSURE THAT THE GOOSENECK IS ‘GROUNDED’ TO YOUR CHOSEN BASE ON ASSEMBLY.**

CT Manuals/C98

The Old Dairy, Straight Half Mile, Maresfield, East Sussex, TN22 2HH, England  
Telephone: +44(0) 1825 766363 Fax: +44(0) 1825 766361 UK  
E-mail: sales@communication-technology.co.uk Website: www.communication-technology.co.uk

REGISTERED IN ENGLAND NO. 01568506 VAT REGISTRATION NO. GB680 0269 46  
REGISTERED OFFICE: 20 SPRINGFIELD ROAD, CRAWLEY, WEST SUSSEX, RH11 8AD

